



## Product #6663

### TechNiche Phase Change Cooling **BROW PAD INSERTS**

Powered by CoolPax™

- Use additional inserts for continuous relief from the heat
- Inserts sealed in high strength polyurethane
- Compatible with 6621 Phase Change cooling Brow Pad powered by CoolPax™

POWERED BY

## COOLPAX™

CoolPax™ is our Phase Change Material (PCM) cooling technology. It uses a non-toxic liquid that freezes at 58°F/14°C and remains at that temperature for up to 1 hour.

### HOW TO USE :

1. Place CoolPax™ inserts in freezer or ice water for 35-40 minutes
2. Insert activated CoolPax™ into garment pockets
3. CoolPax™ vest or accessory is ready to wear!



### COOLPAX™ Inserts

Polyurethane Outer Material  
**Phase Change Material: 58°F**

**Activation:** Ice Water or Refrigerator

**Activated Duration:** up to 1 hour